

**Notes:**

1. Clean & Rasp Stronghold Block Wall Surface.
2. Apply Base Coat to Clean Pry Block Surface. **(As Per Manufactures Specs)**
3. Apply 2nd Coat to Base Coat over 1st Coat & Mesh To Completely Bury Mesh. **(As Per Manufactures Specs)**
4. Acrylic Stucco Brand Can Specify A Primer Prior To The Top Finish Coat.
5. Apply Exterior Finish Top Coat. **(As Per Manufactures Specs)**